

## Product Power Consumption for Lexmark MS431dw / MS431dn / B3442dw

Product Type	Monochrome Electrophotographic Printer
Default Method to automatically enter mode	Network Standby: 15 minute delay Standby: N/A Off: 3 Day Delay auto-off or switch activated

	Network Standby					Off Mode	Standby Mode <i>w/ Reactivation Function</i>
	All Network Connections	Wired Network	Fax	USB	Wireless		
<b>Measurement Period</b>	24min	20 min	N/A	22 min	22 min	20 min	N/A min
<b>Average Power Consumption</b>	0.85 W	0.83 W	N/A	0.75 W	0.98 W	0.06 W	N/A

Instructions for connecting to/disconnecting from a wireless network can be found in the product User Manual.

Report ID: 20190826-1090-ErP

Public Report generation date: October 21, 2019